

Inflating Farm Tires

Being implements and equipments that ease farm work, condition of their tires determine the time to complete work, quality of work and efficiency of the machine on a particular work.

Tires of farm implements are mounted on a machine depending on the nature of the work to be performed at a particular time and nature of the soil to which it is to be operated on. When inflating tires, ensure never to stay in front of the wheel.

Tire management

When inflating tires, always use safety cage and in field, maintain a safe distance and be tolerant to any kind of noise when inflating using inflation guns. Wear safety out fit for additional safety and check for proper mounting and bead positions before installing safety cage.

Continue by removing valve core, tighten the valve and check manufacturer recommendations for inflating tires. Finally ensure that tires are cold before inflating them and screw on valve.